

Smart Guide

Introduction

Your Smart Phone is Intelligent. Now your accessories can be too.

Thank you for purchasing the Smartcell Powerbank Backup Battery. Please read this Smart Guide Instructional Booklet carefully before using your device.

eatures


Dead battery? Not to worry! The Smartcell Powerbank Backup Battery gives you emergency power for your device while you are on the go. Armed with 3000 mAh of power, this unit can charge up to 2 smartphones or 50% of your monster tablets. Compatible with most USB powered devices, it is stylish, compact, rechargeable, and fits easily in your pocket or purse. As an added bonus, it has a built-in emergency flashlight whenever you need some guiding light!

Never run out of juice again!

Technical Specifications

Input	DC 5V / 0.8A	
Output	DC 5V / IA	
Capacity	3000mAh	
Size	4.06 x 0.9 x 0.9 in	

Identification of Parts



- 1 Flashlight On/Off
- 2 Micro USB input port (Charges Powerbank)
 - 3 USB Output Port (Charges Device)

2

How to Charge Your Powerbank

- Plug the Micro USB Cable into the Powerbank's micro USB input port.
- 2 Connect the USB end of the charge cable into a USB wall charger (not included) or a USB computer charging port.



- 3 A steady red light will illuminate indicating the Powerbank is charging. When fully charged, the light will turn off.
- 4 Charge Powerbank fully before first use, approximately 8-10 hours. Unplug when fully charged.

Using Your Powerbank

- 1 Using a fully charged Powerbank, connect the USB charging cable supplied with your tablet/smartphone/mobile device to the USB port of the Powerbank.
- 2 Connect the other end to your device. Your device will automatically start charging. The Powerbank will be Blue to indicate charging.



3 When your device indicates it is fully charged, unplug it from the Powerbank.

Troubleshooting

- 1 If the Powerbank fails to charge, check the charging adapter and adapter connection.
- If the Powerbank fails to charge your device:
 a) Check the connection between the
 Powerbank and device.
- b) Check if the Powerbank is fully charged.
 c) Ensure that the Powerbank's voltage is compatible with your device's required voltage.
 Consult your device's instruction manual.

Important

- 1 Do not charge and discharge the Powerbank at the same time. This damages the battery's performance.
- 2 Keep the product away from extreme temperatures, flammable items, or damp areas. Do not drop, hit, or throw the product and keep foreign objects away from ports.
- 3 Please fully charge the Powerbank once every 3 months to avoid shortening lifespan. 5



smartphone? smartcell. smart choice!

visit www.smartcellgear.com

Contact Us

Thank you once again for purchasing Smartcell products. If you have any questions or comments about our items, please email support@smartcellgear.com.

If you purchased your item from one of our authorized dealers, please contact the retailer from which you bought your product from to initiate a return/replacement.

Warranty

Please visit www.smartcellgear.com for your product's full warranty information.

-

3